PARTS LIST

TYPE 45 DCOE 152 – PART NO. 19600.060

Dia No.	Qty. Req'd	Description	Part Number		Dia No.	Qty. Req'd	Description	Part Number
1	1	Filter Cover	61002.010		46	2	Idle Mixture Screw Cup Washer	58000.006
2	1	Filter Cover Gasket	41530.024		47	3	Spring	47600.007
3	1	Filter Element	37022.010		48	2	Vacuum Take Off Gasket	64590.008
4	1	Jet Inspection Cover	32376.003		49	2	Pump Jet Gasket	41535.021
5	9	Screw	64700.001		50	1	Throttle Spring	47605.027
6	1	Jet Inspection Cover Gasket	41550.002		51	1	Spring Anchor Plate	52210.006
7a	1	Rubber Top Cover Gasket	41715.011		52	1	Throttle Stop Screw	64625.012
7b	1	Paper Top Cover Gasket	41715.001		53	1	Pump Plunger	58602.003
8	1	Needle Valve	79503.*		54	2	Starter Valve	64330.003
9	1	Plastic Float	41030.034		55	2	Starter Valve Spring	47600.105
10	2	Emulsion Tube Holder	52580.001		56	2	Idle Mixture Screw	64750.003
11	2	Air Corrector Jet	77401.*		57	2	Pump Jet	76801.*
12	2	Idle Jet Holder	52585.006		58	2	Pump Jet 'O' Ring	41565.009
13	2	Emulsion Tube	61450.*		59	2	Pump Jet Cover	61015.008
14	1	Stud	64955.007		60	1	Pump Rod Spring	47600.064
15	2	Main Jet	73401.*		61	1	Pump Rod	10410.015
16	2	Idle Jet	748xx.*		62	2	Starter Jet	75507.085
17	2	Auxiliary Venturi	69602.*		63	2	Pump Demand Valve Ball	58300.003
18	2	Air Horn	52840.001		64	2	Pump Demand Weight	52730.001
19	4	Air Horn Fixing Nut	34715.010		65	2	Pump Demand Valve Cover	58070.008
20	4	Spring Washer	55525.010		66	1	Needle Valve Gasket	83102.120
21	4	Air Horn Tab	52150.004		67	1	Fuel Union Gasket	41530.031
22	2	Main Venturi (Choke)	72116.*		68	1	Fuel Union	10536.035
23	4	Stud	64955.101		69	1	Fuel Union Gasket	41530.024
24	2	Lock Washer	52155.003		70	1	Fuel Union Bold	12715.008
25	2	Air By-Pass Screw Cap	14945.003		71	2	Progression Hole Inspection Cover	61015.009
26	2	Air By-Pass Screw	64750.002		72	1	Float Pin	52000.001
27	2	By-Pass Screw Lock Nut	34705.001		73	1	Choke Cable Clamp	64605.017
28	2	Locking Screw	64840.003		74	2	Starter Air Jet	77505.150
31	2	Lock Washer	55520.004		75	1	Carburetor Top Cover	31734.198
32	2	Throttle Spindle Nut	34710.003		76	1	Plate	52130.003
33	2	Throttle Plate	64005.084		77	2	Washer	55510.128
35	4	Throttle Plate Screw	64520.027		78	2	Sealed Bearing	32650.003
36	1	Bottom Cover Gasket	41640.001		79	2	'O' Ring	41575.019
39	2	Inspection Cover Fixing Screw	64570.009		80	1	Inspection Cover	52135.024
40	2	Choke Cover Fixing Screw	64700.004		81	1	Gasket	41640.021
41	1	Pump Cover Gasket	41640.021		82	1	Pin	58445.001
42	1	Cold Start Unit L/H	32556.002		83	1	Bottom Bowl Cover	32374.008
43	1	Exhaust Bleed	79701.*		84	1	Pump Cam Lever	45082.005
44	2	Idle Mixture Screw O Ring	41565.002		85	1	Throttle Shaft	10005.447
45	1	Throttle Lever	45048.007		86	1	Washer	99024.258
		*Calibrated Parts Require 3						
		Digits To Complete Part Number						
		See Calibrated Parts Section						
		For Sizes						